


Remote Status Alarm Panel

UPS Remote Monitor

FEATURES:

- ▶ Remotely monitor UPS systems from up to 1,000 ft.
- ▶ Visual indication with audible alarm
- ▶ Internal battery backup
- ▶ Multiple AC input options
- ▶ Powder coat finish
- ▶ ETL listed to UL 1778 and CSA certified



C&C^{Power's} Remote Status Alarm Panel (RSAP) is used to remotely monitor the alarm condition and real time state of any UPS. The RSAP is wall mounted and can be located up to 1,000 feet from the UPS. The panel uses LED's to visually display the monitored UPS input status, the output that is being used and any UPS fault conditions. The RSAP also has an audible alarm to warn of UPS fault conditions.

The RSAP is available with multiple AC input options, including a 120 VAC hardwire option and a DC transformer wall plug to be used with any standard 5-15 wall outlet. The panel has an internal battery backup with a battery test button and status LED to indicate when it is time to replace the internal batteries.

RSAP VISUAL STATUS LED'S:

- | | | |
|-------------------------|------------------|---------------------------------------|
| ▶ UPS AC input | ▶ UPS output | ▶ UPS input failure |
| ▶ UPS charger/rectifier | ▶ Load on bypass | ▶ UPS system battery low voltage |
| ▶ UPS system batteries | ▶ UPS fault | ▶ RSAP audible alarm silenced |
| ▶ UPS inverter | ▶ UPS overload | ▶ RSAP internal battery backup status |